

ANGEL LINE



ASSEMBLY INSTRUCTIONS FOR THE CONVERTIBLE CRIBS

DISTRIBUTED BY
 LONGWOOD FOREST PRODUCTS INC.
 201 LAKELAND ROAD BLACKWOOD N.J. 08080

MODEL #921
 CUSTOMER SERVICE: (609)227-5505

WARNING:

- * FAILURE TO FOLLOW THESE WARNINGS AND ASSEMBLY INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.
- * READ ALL INSTRUCTIONS BEFORE ASSEMBLING CRIB. KEEP INSTRUCTIONS FOR FUTURE USE.
- * CHECK FASTENERS PERIODICALLY FOR TIGHTNESS. DO NOT OVER TIGHTEN, THIS MAY CAUSE DISTORTION OR BREAKAGE.
- * BEFORE EACH USAGE OR ASSEMBLY, INSPECT CRIB FOR DAMAGED HARDWARE, LOOSE JOINTS, MISSING PARTS OR SHARP EDGES. DO NOT USE CRIB IF ANY PARTS ARE MISSING OR BROKEN. ASK YOUR DEALER OR WRITE TO ANGEL LINE FOR REPLACEMENT PARTS.
- * WHEN CHILD IS ABLE TO CLIMB OUT OR REACHES THE HEIGHT OF 35 INCHES THE CRIB SHALL NO LONGER BE USED.
- * DO NOT PLACE CRIB NEAR A WINDOW WHERE CORDS FROM BLINDS OR DRAPES MAY STRAGGLE A CHILD.
- * REPLACE TEETHING RAILS IF DAMAGED OR LOOSE.
- * NEVER USE PLASTIC SHIPPING BAGS OR OTHER PLASTIC FILM AS MATTRESS COVER.. THEY CAN CAUSE SUFFOCATION.
- * IF REFINISHING, USE A NON-TOXIC FINISH SPECIFIED FOR CHILDREN'S PRODUCTS.
- * ANY MATTRESS USED IN THIS CRIB MUST BE AT LEAST 27-1/4" BY 51-5/8" WITH A THICKNESS NOT EXCEEDING 6"
- * DAILY CHECK THAT THE CRIB SPRING IS SECURELY ATTACHED TO EACH OF THE HANGER BRACKETETS.
- * DO NOT TIE DECORATIONS OR TOYS BETWEEN THE CRIB SIDE RAILS AS CHILD MAY BE CAUGHT OR STRANGLED.

TO RAISE THE DROP SIDE RAIL :

Raise the drop side rail. It will automatically lock into the up position.

TO LOWER DROP SIDE RAIL :

Life the drop side slightly. Kick the foot release on the stabilizer bar toward inside of the crib and release the drop side rail.

TOOLS REQUIRED TO ASSEMBLE CRIB :


single slotted & phillips screw drivers.

CRIB ASSEMBLY HARDWARE


CRIB COMPONENTS	Q'TY
1. DROP SIDE PANEL	1
2. STATIONARY SIDR	1
3. HEAD BOARD	2
4. MATTRESS SUPPORT	1
5. STABILIZER BAR	1
6. SLIDING MATAL RODS	2
7. TOP RAIL	1
8. GUARD RAIL	1
(USE FOR TODDLER BED)	

CONNECTION HARDWARE

A ROD HOLDER
ANGLE
4 PCS



B DROP GATE
SHOE
2 PCS



C PLASTIC ROD
BUSHING
2 PCS



D 3/4" BOLT
.....
6 PCS



E LOWER
SPRING
2 PCS



F UPPER
SPRING
2 PCS



G WOOD
SCREW
24 PCS



H WASHERS
.....
2 PCS



I BARREL
NUT
4 PCS




J 7/8" BOLTS
WITH WASHERS
4 PCS




L BRACKET
4 PCS




M REAR CASTERS
(WITHOUT BRAKE)
2 PCS




N FRONT CASTERS
.....
2 PCS




K 2-3/4" BOLTS ...
4 PCS



O WRENCH



THE FINAL ASSEMBLED CRIB WILL LOOK LIKE THIS



ASSEMBLE THE FULL SIZE CRIB

FIG 1. Line up the pilot holes and attach the brackets (L), rod holder angles (A) to the head & foot boards using the screws (G)




FIG 2. Connect the stabilizer bar to the head & foot boards using the bolts (J). (Note: Make sure the bracket at end of the stabilizer bar is toward outside of the crib and the foot release bar is in the inside face of the stabilizer bar). Swing out 4 hangers at corner of the mattress support carefully. Decide the height of the mattress support you like to have. Bolt the mattress support to the bracket (L) using 3/4 bolts (D). Make sure the mattress support is level.





FIG 3. Install the stationary side. Fit the top rail into the dowel of head & foot boards. Put the washers (H) in bolts (K). Insert the barrel nuts (I) into bottom rail. Line up bolt (K) and nut (I) by using single slotted screw driver on the barrel nut and Phillips screw driver on the barrel nut and tighten the bolt (K) into barrel nut (I).



INSTALL THE DROP SIDE





FIG 4. Prepare the drop side. Attach the gate shoes (B) on the inside face of the bottom rail using the screws (G). Make sure the "up" is facing you and toward the top rail. Insert the plastic bushings (C) into the holes at both ends of the top rail.

FIG 5. Install the drop side. Insert the sliding rod (G) through the bushing (C) in the top rail, and through the upper rod holder angle (A), upper spring (F), bottom rail, lower spring (E) and lower rod holder angle (A). Secure the top of the sliding rod on the head & foot board using the 1/4" bolts (D).





FIG 6. Insert the casters into bottom of posts. Release the brake on the casters and you are ready to use.



NOTE: Keep the guard rail (7) and the remaining bolts (K), barrel nuts (D) to use for the toddler bed in the future.